MULTI-ZONE

BATTERY
A/C CLUTCH CONTROL OUTPUT
A/C CLUTCH CONTROL OUTPUT
A/C PRESSURE 5 VOLT SUPPLY
A/C PRESSURE SIGNAL
A/C PRESSURE GROUND
AAT SIGNAL
SENSOR GROUND
BLOWER MOTOR SUPPLY
FUSED IGNITION SWITCH OUTPUT (RUN)
CIRCUIT BOARD TERM. (SERVICEABLE)
RELAY- BLOWER MOTOR- HIGH
FUSE J59 30A
FUSE F13 50A
FUSE M11 10A
CIRCUIT BOARD TERM. (SERVICEABLE)
RELAY- RUN
FUSE M34 10A
MODULE- TOTALLY INTEGRATED POWER
PANEL LAMPS DRIVER
GROUND
HVAC MUX RETURN
REAR BLOWER SIGNAL
5 VOLT SUPPLY
REAR BLOWER ON INDICATOR DRIVER
REAR A/C TEMP CONTROL SIGNAL
REAR MODE DOOR DRIVER (B)
SWITCH- REAR BLOWER CONTROL
SENSOR GROUND
AUTO HEADLAMPS SIGNAL
SENSOR- SUN
DIESEL
GAS
A/C CLUTCH CONTROL
CLUTCH- A/C COMPRESSOR
MODULE- POWERTRAIN CONTROL
A/C PRESSURE 5 VOLT SUPPLY
A/C PRESSURE SIGNAL
A/C PRESSURE RETURN
TRANSDUCER- A/C PRESSURE
AAT SIGNAL
SENSOR GROUND
SENSOR- AMBIENT AIR TEMPERATURE
BLOWER MOTOR SUPPLY
MOTOR- BLOWER
BLOWER MOTOR SUPPLY
REAR FAN SENSE RETURN
MOTOR- BLOWER- REAR
FUSED B(+)
FUSED IGNITION SWITCH OUTPUT (RUN)
TO OTHER MODULES
CAN H(-)
CAN H(+)
PANEL LAMPS DRIVER
HVAC MUX RETURN
REAR BLOWER SIGNAL
5 VOLT SUPPLY
REAR BLOWER ON INDICATOR DRIVER
REAR A/C TEMP CONTROL SIGNAL
REAR MODE DOOR DRIVER (B)
SENSOR GROUND
AUTO HEADLAMPS SIGNAL
MODULE- A/C HEATER
GROUND
REAR BLOWER HIGH SPEED
REAR BLOWER LOW
REAR BLOWER MEDIUM
BLOWER MOTOR HIGH DRIVER
BLOWER MOTOR MID DRIVER
BLOWER MOTOR A/C DRIVER
BLOWER MOTOR LOW DRIVER
EVAPORATOR TEMPERATURE SENSOR SIGNAL
SENSOR GROUND
RECIRCULATION DOOR DRIVER
COMMON DOOR DRIVER
BLEND DOOR DRIVER
COMMON DOOR DRIVER
MODE DOOR DRIVER
COMMON DOOR DRIVER-2
PASSENGER BLEND DOOR DRIVER
COMMON DOOR DRIVER 2
REAR BLEND DOOR DRIVER
REAR BLEND DOOR DRIVER
MODE DOOR DRIVER
REAR MODE DOOR DRIVER (A)
GROUND
3.6L
RESISTOR- BLOWER MOTOR- REAR
RESISTOR- BLOWER MOTOR- FRONT
SENSOR- EVAPORATOR TEMPERATURE
ACTUATOR- RECIRCULATION DOOR
ACTUATOR- BLEND DOOR- LEFT
ACTUATOR- MODE DOOR- FRONT
ACTUATOR- BLEND DOOR- RIGHT
ACTUATOR- BLEND DOOR- REAR
ACTUATOR- MODE DOOR