


BATTERY  
A0



E17 C5  
P306  
18  
LG/LB

F6 C6  
P304  
18  
LG/DB

17 C2  
Z902  
14  
BK  
G915A

G15 C7  
G78  
22  
VT

12  
12

14  
14

2 C314  
2

P306  
18  
LG/LB

P304  
18  
LG/DB

B3

B1 C2

A1 C1



A2 C1  
Z911  
20  
BK  
G305