GAS

BATTERY
A0

Z916
19
BK

A0
06
RD

A1
04
RD

J1 | C9

MODULE-
TOTALLY
INTEGRATED
POWER

FUSE
M28
10A

B9 | C2

A209
16
RD

S145

A209
16
RD

29   10 | C1

FUSED B(+)   FUSED B(+)

MODULE-
POWERTRAIN
CONTROL

GEN
FIELD
CONTROL

GEN
SENSE

GROUND   GROUND   GROUND

19 | C2   24   9   18   19 | C1

K20
18
BR/GY

A804
16
RD/VT

Z916
01
BK

Z916
01
BK

Z916
01
BK

S149

A802
08
RD/GY

A801
04
RD/GY

8

8 | C134

S159

1 | C2

B(+)   STARTER

1 | C1   1   2 | C2   GENERATOR

B(+)   GEN
FIELD
CONTROL

GEN
SENSE

G302